


Panic button and Remote vehicle immobilization

Panic button

The panic button is a peripheral that allows the driver to activate an alarm to an emergency situation that is happening, by pressing a button discreetly installed in the vehicle. This warning will inform about the vehicle that generated the alarm, the time and the place where the alarm occurred.

Optionally, a buzzer can be installed to beep an audible warning to the driver, so that the driver receives the confirmation that the warning message has been received.




This tool allows the driver to emit a panic alarm to the Control Center or sent a SMS to an emergency telephone to be determined. This way, the company can take the appropriate action to solve the problem.

Remote vehicle immobilization

This tool allows cutting the vehicle injection remotely, making it impossible to start once the vehicle has stopped.

It is designed to be activated from the Control Center as soon as vehicle theft is detected

**Consult this option with a GMV technician to assess the compatibility with your vehicle.*



In case of theft, the vehicle can be immobilized, facilitating the recovery.